


# CARDIO CLEANING MESSAGES

For peace of mind for facility owners and their exercisers we have developed cleaning messages for our premium consoles. (Discover SE3, SE3 HD, ST, and Cybex 70T)

Customers can choose between the following two options:


## Option 1\* - Locked Machine (Social Distancing)

Make social distancing and cleaning easier with the ability to lock consoles and limit availability of cardio machines.



### How to disable:

Tap left, right, left in the upper corners of the touch screen to unlock the machine, and disable via managers configuration.



**Recommend use:** Facilities that want to lock machines for social distancing protocols or alternate product usage between deep cleanings.


\*Please Note: If both locked (social distancing) and locked (cleaning) are enabled, only the locked message will appear. You cannot use both solutions simultaneously.

## Option 2\* - Locked Machine (Cleaning)

Lock the machine after each workout to allow cleaning by a staff member. A custom screen clearly indicates when the machine is clean and ready for use by a new user.



**How to unlock for next user:** On the Please Wait screen tap left, right, left in the upper corners of the touch screen to unlock. \*The facility must have a cleaning process between workouts for this message to be utilized.




**Recommend use:** Facilities that want clean products in between each use and can train staff on how to unlock machine once thorough cleaning is completed.

# CARDIO CLEANING MESSAGES CONTINUED


## Option 3 - Post workout message

Reminds exercisers to wipe down machine when their workout is over.



**Recommend use:** Facilities that want to provide a straightforward reminder to their exercisers to wipe down the machine.

**How to enable all features in Manager's Configuration:** On the console home screen Tap the LANGUAGE icon to access the SELECT LANGUAGE screen. Tap the lower part of the screen in the following sequence: Lower-Left, Lower-Right, Lower-Left, and Lower-Right.



**Navigate to Configuration - Manager** within the Manager's Configuration menu, and select Enable on one of the three options you prefer. Please Note: If both locked (social distancing) and locked (cleaning) features are enabled, only the locked message will appear. **You cannot use both solutions simultaneously.**

