

PRODUCT INFORMATION

Volume 10

July 2013

User Selectable Languages on 770 Series Cardio Products (including the 790T)

This feature allows users to manually change the system language via the CardioTouch™ opening screen. As the Language button is pressed, it will cycle through the set available languages. The system will reset to the default language at the end of a workout. This feature works with standard LED and E3 View displays.

How is it setup?

This feature will be enabled from the factory. It can be disabled by entering the Toolbox and entering the Language setup section. Once in the Language setup section, press the Include Optional Languages button and turn off the selected languages.

Which selectable languages are available?

English, French, German, Spanish, Swedish, Japanese, Russian, Danish, and Dutch

What are the default selectable languages?

System Language	Default Selectable Languages	
English	Spanish	French
German	Dutch	French
Spanish	English	French
French	English	German
Japanese	English	-
Swedish	Danish	English
Russian	English	-
Danish	German	Swedish
Dutch	German	English

Will the LED display language change?

The language on the LED display will not change.

Will the E3 View display language change?

The language on the E3 View display will match the language selected from the CardioTouch™ opening screen, with the exception of Japanese.

When is it available?

This is a standard feature on products manufactured after June 5th, 2013. (software version 1.28.001 and higher).

Can the 770 series products in the field be updated with this feature?

Yes, with a system software update. However, this feature will not be set by default when field updated. Standard costs for software field updates will apply.

What is the price?

There is no price increase associated with this feature.

What is the impact to the warranty?

There is no impact to the product warranty.

How is the Toolbox accessed?

With user selectable languages enabled:

Press and hold the Language button until you hear a double beep (approx. 6 seconds).

With user selectable languages disabled:

Press and hold the Cybex logo until you hear a double beep (approx. 6 seconds).

What does the home screen look like?



Opening screen with selectable languages enabled (default from the factory)



Opening screen with selectable languages disabled

