



Preventative Maintenance & Site Survey Checklist

A Preventative Maintenance (PM) is a complete diagnostic inspection with all necessary adjustments and lubrication of the equipment.

A Site Survey is an inspection of an area to identify issues and gather information for an estimate or report to complete identified tasks.

ALL UNITS MUST BE USED & ALL FEATURES FULLY TESTED FOR THIS SITE SURVEY
(Strength with a minimal amount of weight & cardio at both the lowest and the highest speed or resistance)

Please select and inspect only the areas and products that apply for each location

- | | | |
|---|--|--|
| <p><u>Treadmills:</u></p> <ul style="list-style-type: none"> <input type="checkbox"/> Full Cosmetic Inspection for Damage & Rust <input type="checkbox"/> Console Leveling <input type="checkbox"/> Headphone Jack Functionality (if Needed) <input type="checkbox"/> Noise Inspection Process <input type="checkbox"/> Stop Magnet Inspection <input type="checkbox"/> Power Inspection <input type="checkbox"/> All Button Response & Functionality <input type="checkbox"/> Heartrate Functionality <input type="checkbox"/> Belt Alignment Inspection <input type="checkbox"/> Belt & Deck Inspection <input type="checkbox"/> Full Incline Functionality <input type="checkbox"/> Full Speed Functionality <input type="checkbox"/> Line Cord & Bracket Damage & Inspection <input type="checkbox"/> Bolt & Screw Inspection – Rust, Loose or Damg. <input type="checkbox"/> Lift Motor Lubrication (Wheel Bearing Grease) <p><u>Cross-Trainers:</u></p> <ul style="list-style-type: none"> <input type="checkbox"/> Full Cosmetic Inspection for Damage & Rust <input type="checkbox"/> Headphone Jack Functionality (if Needed) <input type="checkbox"/> Noise & Alignment Inspection Process <input type="checkbox"/> Power Inspection <input type="checkbox"/> Battery VDC Inspection <input type="checkbox"/> All Button Response & Functionality <input type="checkbox"/> Heartrate Functionality <input type="checkbox"/> Full Resistance Functionality (Gen, Alt, RPMs, etc.) <input type="checkbox"/> Pedal Inspection <input type="checkbox"/> Bolt & Screw Inspection – Rust, Loose or Damg. <p><u>Bikes:</u></p> <ul style="list-style-type: none"> <input type="checkbox"/> Full Cosmetic Inspection for Damage & Rust <input type="checkbox"/> Shroud, Seat and Label inspection <input type="checkbox"/> Headphone Jack Functionality (if Needed) <input type="checkbox"/> Noise Inspection Process <input type="checkbox"/> Power Inspection <input type="checkbox"/> Battery VDC Inspection <input type="checkbox"/> All Button Response & Functionality <input type="checkbox"/> Heartrate Functionality <input type="checkbox"/> Full Resistance Functionality (Gen, Alt, RPMs, etc.) <input type="checkbox"/> Belt & Clutch Inspection <input type="checkbox"/> Pedals Inspection <input type="checkbox"/> Bolt & Screw Inspection – Rust, Loose or Damg | <p><u>PowerMill:</u></p> <ul style="list-style-type: none"> <input type="checkbox"/> Full Cosmetic Inspection for Damage & Rust <input type="checkbox"/> Bolt & Screw Inspection – Rust, Loose or Damg. <input type="checkbox"/> Shroud & Cosmetic Inspection <input type="checkbox"/> Headphone Jack Functionality (if Needed) <input type="checkbox"/> Chain Alignment Inspection <input type="checkbox"/> Soft-Step, Bearing & Rod Inspection <input type="checkbox"/> Noise Inspection Process <input type="checkbox"/> Power Inspection <input type="checkbox"/> All Button Response & Functionality <input type="checkbox"/> Heartrate Functionality <input type="checkbox"/> Full Resistance Functionality <input type="checkbox"/> Line Cord & Bracket Damage & Inspection <input type="checkbox"/> Break Functionality <input type="checkbox"/> Preventative Maintenance (See Video & Job Aid) <p><u>Arc-Trainer:</u></p> <ul style="list-style-type: none"> <input type="checkbox"/> Full Cosmetic Inspection for Damage & Rust <input type="checkbox"/> Noise Inspection Process <input type="checkbox"/> Head Unit Movement Test (Worm-Gear Play) <input type="checkbox"/> Headphone Jack Functionality <input type="checkbox"/> Full Incline Functionality <input type="checkbox"/> Power & Battery Inspection <input type="checkbox"/> All Button Response & Functionality <input type="checkbox"/> Heartrate Functionality <input type="checkbox"/> Full Resistance Functionality <input type="checkbox"/> Rubber Gasket Inspection <input type="checkbox"/> Cybex Touchscreen Calibration & Function <input type="checkbox"/> Lift Motor Lubrication (Wheel Bearing Grease) <p><u>SCIFIT Pro Series & StepOne:</u></p> <ul style="list-style-type: none"> <input type="checkbox"/> Full Cosmetic Inspection for Damage & Rust <input type="checkbox"/> Seat Functionality and Seat Bearing Inspection <input type="checkbox"/> SCIFIT Console Functionality, Button Response & Touchscreen Calibration <input type="checkbox"/> Noise Inspection <input type="checkbox"/> Power & Battery Inspection <input type="checkbox"/> Pedals Inspection (if Needed) <input type="checkbox"/> Bolt & Screw Inspection – Rust, Loose or Damg <input type="checkbox"/> Chain Lubrication (30W Non-Detergent Oil) <input type="checkbox"/> Pro Series Bi-Directional Resistance Function <input type="checkbox"/> Pro Series Chain Tension Test & Lubrication <input type="checkbox"/> Pro Series Hand Crank Alignment Verification <input type="checkbox"/> StepOne "Total Steps" Counter Inspection | <p><u>Strength:</u></p> <ul style="list-style-type: none"> <input type="checkbox"/> Cable / Belt Inspection <input type="checkbox"/> Pulley Inspection <input type="checkbox"/> Seat Adjustment Functionality <input type="checkbox"/> Work Arms Level & Functional <input type="checkbox"/> Range of Motion Inspection <input type="checkbox"/> Weight Stack Pin Inspection <input type="checkbox"/> Guide Rod Lubrication (Multi-Purpose Oil) <input type="checkbox"/> Guide Rod Retainer Inspection <input type="checkbox"/> Grip & Pad Inspection for Damage <input type="checkbox"/> Pad Label Removal <input type="checkbox"/> Weight Stack Label Inspection <input type="checkbox"/> Weight Tree/Horn Label Inspection <input type="checkbox"/> Carabiner Inspection <input type="checkbox"/> Bolt & Screw Inspection – Rust, Loose or Damg. <input type="checkbox"/> Paint Damg & Rust Inspection <input type="checkbox"/> Shroud, Cosmetic and Label inspection <input type="checkbox"/> Bumper & Counterweight Inspection <input type="checkbox"/> Accessory Inventory and inspection <input type="checkbox"/> Weight Plate / Dumbbell Inventory & Inspection <input type="checkbox"/> Adjustable Pulley Carriage Inspection <p><u>Integrity C & Legacy LED Consoles Only:</u></p> <ul style="list-style-type: none"> <input type="checkbox"/> Software Update Verification <input type="checkbox"/> Full Inspection of all Features & Functions <input type="checkbox"/> 5 Amp / 12VDC (60W) Power Supply Inspection <input type="checkbox"/> All Button Response & Functionality <input type="checkbox"/> Headphone Jack Functionality <p><u>Attachable TV:</u></p> <ul style="list-style-type: none"> <input type="checkbox"/> 5 Amp / 12VDC Power Supply <input type="checkbox"/> Channels Scanned & Labeled <input type="checkbox"/> Power Inspection <input type="checkbox"/> Channel Changing Functionality <input type="checkbox"/> Volume Changing Functionality <input type="checkbox"/> Headphone Jack Functionality <p><u>Rower:</u></p> <ul style="list-style-type: none"> <input type="checkbox"/> Full Cosmetic Inspection for Damage & Rust <input type="checkbox"/> Seat Inspection <input type="checkbox"/> Console Functionality, Button Response <input type="checkbox"/> Visual Inspection of Tank/Water Line Level <input type="checkbox"/> 6 Month Water Treatment Tablet |
|---|--|--|

**For additional information, parts or service, our Contact Center is available at
1-888-PLANET5 (888-752-6385) or planetfitness@lifefitness.com**

